

Please Note:

This document is provided as a dimensional reference and should not be printed as a drilling template unless it can be correctly scaled to 100% by your printer.

Instructions are printed to scale if cylinder hole measures 32mm.

ASSA ABLOY Australia Pty Limited 235 Huntingdale Road, Oakleigh Victoria, 3166 Australia

info.au@assaabloy.com assaabloy.com.au ASSA ABLOY New Zealand Ltd. 6 Armstrong Road Albany, North Shore City, 0632 New Zealand

info.nz@assaabloy.com assaabloy.co.nz



3. INSTALL CYLINDER AND MOUNTING PLATE

- 1. Fix MOUNTING PLATE to door with four woodscrews supplied.
- 2. Align Notch on HUB with vee on mounting plate.
- 3. Insert and locate blade end of spindle into hub from outside of door. Mark and cut spindle to length. (19 mm (³/₄ ") from Door Face).
- 4. Isert spindle into digital lock drive gear with blade end facing out.
- Realign notch on hub with vee on mounting place. Secure digital lock with mounting screw through cup washer and into top hole. Cut screw if required. Ensure blade end of spindle engages in hub.
- 6. Place rear digital lock mounting screw through slot in hub and secure digital lock to door.
- 7. Rotate HUB 90 degrees by entering code of Digital Lock and turning knob. Hold in position and screw



4. INSTALL CASE

- 1. Rotate lever fully clockwise to HOLD BACK position.
- 2. Ensure notch on hub is aligned with vee on mounting plate.
- Fit case body to mounting plate as shown.
- 3. Secure the case to the mounting plate using two case mounting screws.



5. INSTALL STRIKE

- 1. Locate strike in mortice on door jamb with thin side facing towards door.
- 2. Secure the two woodscrews on strike face.
- 3. Drill 3 mm ($\ensuremath{\mathscr{V}}$) dia X 25 mm (1 ") deep through hole located in base of strike cavity.
- 4. Secure the third woodscrew as show below.





LOCKWOOD GUARANTEE

ASSA ABLOY Australia Pty Limited ("ASSA ABLOY") guarantees its Lockwood products against defects in workmanship and materials. If within the normal working life of a product it is found to be defective, ASSA ABLOY will supply the same or equivalent product free of charge. All electrical and electronic components used in ASSA ABLOY's range of products excluding batteries are guaranteed for a period of 12 months from the date of proof of purchase, unless stated otherwise.

ASSA ABLOY assumes no liability under the guarantee for the following:

- 1. Improper installation or failure to follow fitting instructions.
- 2. Failure due to improper maintenance.
- Failure due to fair wear and tear.
 Indirect or consequential loss or damage.
- mained or consequential loss or damages.
 Cost of removal and/or replacement.
- 6. Cost of freight and/or travelling time.
- 7. The plated finishes Florentine Bronze, Architectural Bronze, Polished Brass, Gold and Satin Brass, "which" are classified as soft finishes. As deterioration is possible under some environmental conditions, these finishes are excluded from this guarantee.
- Any modification or repairs to a product, as supplied, unless authorised by ASSA ABLOY Australia Pty Limited.
- 9. Use of replacement parts other than authorised parts.
- 10. Malfunction or failure of the product due to the use of non-genuine Lockwood parts.
- 11. Malfunction or failure of the product due to the use of non-specified batteries.

Nothing in the ASSA ABLOY Australia Pty Limited guarantee excludes, restricts or modifies any condition, warranty, right or liability implied or protected by law where to do so would render the Guarantee, or any part of it, void.

